


LKK Noodle & Pasta Cooker

Installation Specification





Technical Specifications:

The appliance installation must comply with the installation & ventilation requirements of AS/NZS5601.1, Australian Standard, "Gas Installations" any local Authority regulation and the Manufacturer's installation instructions.

Warning: DO NOT install LKK Noodle & Pasta Cooker in marine environment such as on a boat or outdoors in sea breeze. Due to the salt in marine environment, it may cause unnecessary rusting to the appliance.

Inlet Connections: Gas 3/4" (20mm)

Water ½" (15mm)

Drainage: 3/4" (20mm) Located behind front door directly on the bottom of the tank.

Installation:

Gas point entry is 220mm from floor and 56mm fromt right edge when facing the back side of the appliance. A regulator is supplied for each burner with the applience.

Maxitrol, RV48 AGA#3088 (Natural Gas)

Maxitrol, RV48 AGA#3088 (L.P.G)

MUST be installed by a certified Gas Fitter or Plumber.

Commissioning:

Upon installation, the installer MUST comission the regulator to the required pressure as stated on dataplate. Failure to do so will result in under performance of appliance & void in warranty.

Troubleshoot:

If any of the following problems persist, pilot not lighting, gas or water leak, please call LKK for more information. A gas *certificate of compliance on completion* of all gas installation work on LKK Food Equipment may be required to be sited upon carrying out warranty work. Unlicensed gas work is illegal and will not be covered under warranty. LKK reserves the right to report any illegal gas work.